

BH76 Bluetooth Headset




Quick Start Guide
V1.2

1 Package List




BH76



BHC76 Wireless Charging Stand
Power Adapter
Optional



USB 2.0 Cable (USB-A to USB-C)



BT51-A Dongle or BT51-C Dongle




Carrying Case




Quick Start Guide

Note: We recommend that you use the included accessories, and other accessories may have compatibility issues that prevent them from working properly.

2 Charging




USB Charging



Wireless Charging (optional)

Note: We recommend to fully charge the headset when using it for the first time. The BHC76 is compatible with devices that support Qi wireless charging, such as wireless charging mobile phones and headsets.

LED Indicator Status




Charging

Fully Charged


Note: It takes two hours for USB charging and three hours for wireless charging to be fully charged.

3 Power on/off




Power on

Power off




4 Pairing and Connecting Device

No Built-in Bluetooth Device




Built-in Bluetooth Device


Step1: Enter Pairing Mode



Step2: Select the Headset from Your Bluetooth Device



5 Call Controls and Busylight




Incoming Call
Talking
Trying to Connect to Teams
Connect to Teams Successfully




Flash Red
Solid Red
Flash Purple
Solid Purple

Note: Only the Teams edition can connect to Teams.


6 Music Controls



7 Customers Button



8 Sound Control




Note: You can set the level of noise cancellation on Yealink USB Connect (desktop client) or Yealink Connect (mobile app). If you are in Noise Canceling mode, you might not hear the ambient sound. It depends on ambient conditions and the type or volume of audio playback. Do not use the headset in places where the inability to hear ambient sounds would be dangerous.

9 Replace Ear Cushions



10 Software Management



Notes for BHC76 (optional)

- 1. Please use the power adapter provided by Yealink to get a more efficient charging experience.
- 2. Please do not place any metal and magnetic cards on the charging board to avoid abnormalities and damage to the charger.
- 3. Please do not charge too far away from the charging sign to get a more efficient charging experience.
- 4. During use, if you find the charging board or the charged device is overheated and the charging stops (the indicator light keeps flashing), you need to remove the charged device until it cools down, and then try charging again.
- 5. The indicator light of the charging stand keeps flashing, and it may be the following three situations:
 - The location of the charged device is not placed correctly. You need to replace it. After calibrating the charging position, you can charge the device normally until the indicator light is always on.
 - The charging stand has an overheating alarm. After the mobile phone or the charging stand cools down, it will stop flashing automatically and enter the normal charging state.
 - Metal or magnetic cards may be placed on the charging board, and please remove them.

Safety Guide for BHC76 (optional)

- 1. Do not disassemble the product by yourself or bring it near fire and water to avoid short circuit leakage or damage to the product.
 - 2. Do not use the product in high temperature, humidity, and corrosive environment to avoid damaging the circuit and causing failure to charge or other failures.
 - 3. Do not expose the product to corrosive liquids. Otherwise, it will cause severe damage.
 - 4. Do not disassemble or re-equip the product for any reason to avoid secondary failure and burnout.
 - 5. Do not place the product below -10°C or above 60°C.
 - 6. Do not knock, throw or shake the product because rough methods will damage the internal circuit board structure.
- If you need to know the product warranty information, please visit <https://ams.yealink.com>.

About Yealink
Yealink (Stock Code: 300628) is a global brand that specializes in video conferencing, voice communications and collaboration solutions with best-in-class quality, innovative technology and user-friendly experience. As one of the best providers in more than 140 countries and regions, Yealink ranks No.1 in the global market share of SIP phone shipments (Global IP Desktop Phone Growth Excellence Leadership Award Report, Frost & Sullivan, 2019).
Copyright © 2022 YEALINK(XIAMEN) NETWORK TECHNOLOGY CO., LTD.
All rights reserved. No parts of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, photocopying, recording, or otherwise, for any purpose, without the express written permission of Yealink(Xiamen) Network Technology CO., LTD.
Technical Support
Visit Yealink WIKI (<http://support.yealink.com/>) for firmware downloads, product documents, FAQ, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (<https://ticket.yealink.com>) to submit all your technical issues.



430104002179



YEALINK(XIAMEN) NETWORK TECHNOLOGY CO., LTD.
Web: www.yealink.com
Addr: No.1 Ling-Xia North Road, High Tech Park, Huli District, Xiamen, Fujian, P.R.C.
Copyright © 2022 Yealink Inc. All rights reserved.




1 包装清单




说明：我们建议您使用自带的配件，其他配件可能存在兼容性问题，无法正常工作。

2 充电




说明：
首次使用时建议将耳机充满电。
BHC76 兼容支持 Qi 无线充电的设备，如无线充电手机、耳机。

LED 状态指示灯




说明：USB 充满电需要两个小时，无线充电需要三个小时才能充满。

3 开 / 关机




4 配对与设备连接 无蓝牙设备




内置蓝牙设备


第一步：进入配对模式



第二步：从蓝牙设备列表中选择耳机




5 通话控制与忙碌指示灯




说明：只有 Teams 版本支持与 Teams 建立连接。


6 音乐控制



7 客户键



8 声音控制




说明：
• 降噪模式级别可以在 Yealink USB Connect (电脑端) 或者 Yealink Connect (移动端) 设置。
• 在开启降噪模式可能听不到环境声音，具体取决于环境状况和音频播放的类型 / 音量。请勿在因无法听到环境声音就会造成危险的地方使用耳机。

9 更换耳罩



10 软件管理

Yealink USB Connect (电脑端)



从亿联网站 <https://www.yealink.com/product/yuc> 下载。

说明：需要搭配 0.34.x.x 或更高版本的 Yealink USB Connect 使用。

Yealink Connect App (移动端)



从 iOS 系统 或 Android 系统的应用商店下载 Yealink Connect App。

BHC76 说明

- 为了让您得到更高效的充电体验，请使用提供的电源适配器。
 - 请勿在充电板上放金属杂物或磁卡，避免充电底座异常或损坏。
 - 为了让您得到更高效的充电体验，充电设备请勿离充电闪电标志太远。
 - 使用过程中如遇到充电板或充电设备过热导致停止充电（指示灯一直闪烁），请取下充电设备，待冷却后，重新尝试充电。
- 指示灯一直闪烁，可能下面三种情况：
- 位置没放置好，重新放置充电设备校准位置后直到指示灯常亮，正常充电。
 - 为保证一定的安全，充电底座具有过热报警，待手机或充电设备自身冷却后，会自动消除闪烁情况，进入正常充电状态。
 - 充电板上放金属杂物或磁卡，需取下金属物或磁卡。

BHC76 安全须知

- 请勿将本产品自行拆卸或投入火中、水中，避免造成短路漏电或损坏产品。
- 请勿在高温、潮湿或腐蚀性环境下使用本产品，避免损坏电路导致不能充电或其他故障。
- 请勿将产品接触腐蚀性液体，否则会造成严重损坏。
- 请勿以任何理由拆卸或改装本产品，避免造成二级故障及烧毁。
- 请勿将产品置于小于 -10°C 或者大于 60°C。
- 请勿敲打、扔掷或强烈震动本产品，粗暴方式会损坏内部电路板结构。

如需了解产品保修信息，请访问 <https://ams.yealink.com>。

Regulatory Notices

Operating Ambient Temperature

- Operating temperature: +2 to 104°F (0 to 40°C)
- Relative humidity: 5% to 90%, noncondensing
- Storage temperature: -22 to 107°F (-30 to 70°C)

Warning

Our product warranty is limited only to the unit itself, when used normally in accordance with the operating instructions and the system environment. We are not liable for damage or loss resulting from the use of this product, or for any claim from a third party. We are not liable for problems with Yealink device arising from the use of this product, we are not liable for financial damages, lost profits, claims from third parties, etc., arising from the use of this product.

Explanation of the symbols

- DC symbol
- is the DC voltage symbol.
- WEEE Warning symbol

Restriction of Hazardous Substances Directive (RoHS)

This device complies with the requirements of the EU RoHS Directive. Statements of compliance can be obtained by contacting support@yealink.com.

Safety Instructions

Save these instructions. Read these safety instructions before use!

General Requirements

- Before you install and use the device, read the safety instructions carefully and observe the situation during operation.
- During the process of storage, transportation, and operation, please always keep the device dry and clean, avoid collision and crush.
- Please attempt not to dismantle the device by yourself. In case of any discrepancy, please contact the appointed maintenance center for repair.
- Please refer to the relevant laws and statutes while using the device. Legal responsibility for radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio communications, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Place the device at a well-ventilated place. Do not expose the device under direct sunlight.
 - Keep the device dry and free of dust.
 - Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials.
 - Keep the device away from heat sources or bare fire, such as a candle or an electric heater.

Operating Requirements

- Do not let a child operate the device without guidance.
- Do not let a child play with the device or any accessory in case of accident.
- Please use the accessories provided or authorized by the manufacturer only.
- The power supply of the device shall meet the requirements of the input voltage of the device. Please use the provided surge protection power socket (except PSS standard). Operation is subject to the following two conditions:
 - The device may not cause interference, and
 - the device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the manufacturer.
- Before plugging or unplugging any cable, make sure that your hands are completely dry.
- Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbasin, kitchen sink, or near a swimming pool.
- During a thunderstorm, stop using the device and disconnect it from the power supply. Unplug the power plug and the Auxiliary Digital Subscriber Line (ADSL) twisted pair (the radio frequency cable) to avoid lightning strike.
- If the device is left unused for a longer time, disconnect it from the power supply and unplug the power plug.
- When there is a smoke or fire, the device, or some abnormal noise, smell, uncontrolled environment. The equipment should be limited and operated with great immediacy.
- Contact the specified maintenance center for repair.
- Do not insert any object into equipment slots that is not part of the equipment's auxiliary power.
- Before connecting a cable, connect the grounding cable of the device first. Do not disconnect the grounding cable until you disconnect all other cables.

Battery Requirements

- Do not remove the battery into water, which could short-circuit and damage the battery.
- Do not remove the battery to an open flame or leave the battery where it could be subjected to extremely high temperatures, which could cause the battery to explode.
- Do power the handset off before removing the battery.
- Do not try to use the battery for the power supply of any device other than the handset.

EU Regulatory Information

Support Frequency Bands and Power:
Bluetooth 2.4GHz - 20 dBm

Contact Information

YEALINK NETWORKS TECHNOLOGY CO. LTD.
309, 3rd Floor, No. 16 Yan Ding North Road, Huai District, Xiamen City, Fujian, P.R.C.
YEALINK (EUROPE) NETWORKS TECHNOLOGY B.V.
Smeetskylaan 3127, Alrum Building, 8th floor, 1077XZ Amsterdam, The Netherlands
YEALINK (USA) NETWORKS TECHNOLOGY CO., LTD.
699 Pacific Street Suite 2200, Fulton, Atlanta, GA, 30309, USA
Made in China