



WH62 Mono Portable & WH62 Dual Portable


DECT Wireless Headset



^{*} The pictures in this guide take the Teams version as an example.


Quick Start Guide V1 2

1 Package Contents




Note: The package consists of one WHM621 or WHD622 headset and one WDD60. Some third-party accessories may be incompatible with the headset, so we strongly recommend that you use Yealink accessories only.

2 Charge the Headset




3 Power on/off



4 Pair WDD60 with the Headset (optional)


In the event that the WDD60 is unpaired or bought separately, you will need to pair the WDD60 with the headset.

Put the headset into pairing mode



Put the WDD60 into pairing mode


You can connect the WDD60 to the PC or IP phone.






5 Connection

The headset and the WDD60 are pre-paired and ready for use.






6 Usage




•	Answer or end a call	Press the Call Control Button
	Reject a call	Double-press the Call Control Button
	Hold or resume a call	Hold the Call Control Button for 2s
23	Volume up or down	Press the Volume Up/Down Button
4	Mute or unmute your microphone	Press the Mute Button or move the microphone boom-arm up/down

7 Wear the Headset



Note: When you are in music mode, you can wear the headset with the microphone in your right ear, and you will have a better stereo sound experience.

8 Replace Ear Cushions



9 Software

Yealink USB Connect

Yealink provides a USB device manager client - Yealink USB Connect, which you can use to personalize and manage your Yealink headsets.

Download it from the Yealink website https://www.yealink.com/product/yuc.

Regulatory Notices

Operating Ambient Temperatures

- Operating temperature: +32 to 104°F (0 to 40°C)
- Belative humidity: 5% to 90%, noncondensing
- Storage temperature: -22 to +160°F (-30 to +70°C)

Warranty

Our product warranty is limited only to the unit itself, when used normally in accordance with the operating instructions and the system environment. We are not liable for damage or loss resulting from the use of this product, or for any claim from a third party. We are not liable for problems with Yealink device arising from the use of this product; we are not liable for financial damages, lost profits, claims from third parties, etc., arising from the use of this product.

Explanation of the symbols

- DC symbol
- is the DC voltage symbol.
- WEEE Warning symbol

To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Restriction of Hazardous Substances Directive (RoHS)

This device complies with the requirements of the EU RoHS Directive. Statements of compliance can be obtained by contacting support@ vealink.com.

Safety Instructions

Save these instructions. Read these safety instructions before use!

A General Requirements

- . Before you install and use the device, read the safety instructions carefully and observe the situation during operation.
- During the process of storage, transportation, and operation, please always keep the device dry and clean, avoid collision and crash.
- . Please attempt not to dismantle the device by yourself. In case of any discrepancy, please contact the appointed maintenance center · Please refer to the relevant laws and statutes while using the device. Legal rights of others should be respected as well.

A Environmental Requirements

- Place the device at a well-ventilated place. Do not expose the device under direct sunlight.
- . Keep the device dry and free of dust.
- . Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials.
- Keep the device away from any heat source or bare fire, such as a candle or an electric heater.

♠ Operating Requirements

- . Do not let a child operate the device without guidance.
- Do not let a child play with the device or any accessory in case of accidental swallowing.
- · Please use the accessories provided or authorized by the manufacturer only.
- The power supply of the device shall meet the requirements of the input voltage of the device. Please use the provided surge protection nower socket only
- Before plugging or unplugging any cable, make sure that your hands are completely dry.
- . Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbowl, kitchen sink, wet basement or near a swimming pool. During a thunderstorm, stop using the device and disconnect it from the power supply. Unplug the power plug and the Asymmetric
- Digital Subscriber Line (ADSL) twisted pair (the radio frequency cable) to avoid lightning strike.
- If the device is left unused for a rather long time, disconnect it from the power supply and unplug the power plug.
- . When there is smoke emitted from the device, or some abnormal noise or smell, disconnect the device from the power supply, and unplug the power plug immediately.
- . Contact the specified maintenance center for repair.
- . Do not insert any object into equipment slots that is not part of the product or auxiliary product.
- . Before connecting a cable, connect the grounding cable of the device first. Do not disconnect the grounding cable until you disconnect all other cables.

↑ Battery Requirements

- . Do not immerse the battery into water, which could short-circuit and damage the battery.
- . Do not expose the battery to an open flame or leave the battery where it could be subjected to extremely high temperatures, which could cause the battery to explode.
- . Do power the handset off before removing the battery.
- . Do not try to use the battery for the power supply of any device other than this handset.
- . Do not open or mutilate the battery, released electrolyte is corrosive and may cause damage to your eyes or skin.
- . Use only the rechargeable battery pack delivered with the handset or those rechargeable battery packs expressly recommended by
- . Defective or exhausted battery should never be disposed of as municipal waste. Return old battery to the battery supplier, a licensed battery dealer or a designated collection facility.

Cleaning Requirements

- . Before cleaning the device, disconnect it from the power supply.
- . Use a piece of soft, dry and anti-static cloth to clean the device.
- Keep the power plug clean and dry.

Troubleshooting

The unit cannot supply power to Yealink device.

There is a bad connection with the plug.

- 1. Clean the plug with a dry cloth.
- 2. Connect it to another wall outlet.
- The usage environment is out of operating temperature range.
- 1. Use in the operating temperature range.
- The cable between the unit and the Yealink device is connected incorrectly.
- 1. Connect the cable correctly.
- You cannot connect the cable properly.
- You may have connected a wrong Yealink device.
- Use the correct power supply.
- Some dust, etc., may be in the port.
- 1. Clean the port.

Contact your dealer or authorized service facility for any further questions.

FCC CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful inference, and (2) this device must accept any interference received, including inderference than ye cause under-sired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Relationship to the Complete the Complete

-- Regrient or relocate the receiving antenna

- —Increase the separation between the equipment and receiver
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.
- The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED WARNING

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présentappareilestconforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareildoit accepter tout brouillageradioélectriquesubi, mêmesi le brouillageest susceptible d'encompromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003. Cetappareilnumérique de la classe B estconformeà la norme NMB-003 du Canada.

Les communications effectuées au moyen de cetappareil ne sont pas nécessairement protégées des indiscrétions.

EU Regulatory Information

Support Frequency Bands and Power:

DECT 1.8GHz-1.9GHz< 24 dBm Contact Information

YEALINK NETWORK TECHNOLOGY CO.,LTD.

309, 3rd Floor, No.16, Yun Ding North Road, Huli District.

Xiamen City, Fujian, P.R.C

YEALINK (EUROPE) NETWORK TECHNOLOGY B.V.

Strawinskylaan 3127, Atrium Building, 8th floor, 1077ZX

Amsterdam, The Netherlands

YEALINK (USA) NETWORK TECHNOLOGY CO., LTD.

999 Peachtree Street Suite 2300, Fulton, Atlanta, GA, 30309, USA

Made in China

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.
Web: www.yealink.com
Copyright@2022 YEALINK(XIAMEN) NETWORK
TECHNOLOGY CO.,LTD. All rights reserved.